



ALTA PRO

There are no speed limits on the road to excellence.

Faced with the need to provide fast and accurate service for new lens materials and frame designs, combined with environmentally-friendly demands, the Alta Pro is your solution. Nominated for the Silmo d'Or Award 2009.

Alta PRO can handle all of your needs by itself, or combined with either the Alta XL tracer/blocker or the Alta XS tracer/blocker. It realizes wide range of finishes with a significant increase in productivity.

New: increased productivity

New motorization has been developed to optimize the edging algorithms, resulting in up to 43% faster operation and significantly increased productivity.

New TBS (Tilted Bevel System)

Alta Pro integrates a new wheel dedicated to high curvature lenses. The wheel allows you to change the angle of the bevel to match the frame groove angle, and to adjust the back facet up to 3mm.

New: reduced water consumption

Water consumption has been considerably reduced: 5 liters for an edged lens versus 16 liters on average with previous models. Alta Pro is part of a new effort to market products which are environmentally friendly.

ALTA PRO facing the competitors...

Basic bevelled job

CR39 sph -0.25 - Diam 65
Automatic bevel.



ALTA PRO
50% FASTER

Supra job

Polycarbonate sph -4.00 - Diam 75
Groove - Polish - Safety bevel.



ALTA PRO
34% FASTER

Rimless job

Polycarbonate sph -4.00 - Diam 75, 3
3 holes + 1 notch-Polish-Safety bevel.



ALTA PRO
32% FASTER

briot

Briot International

2 rue Roger Bonnet - 27340 PONT DE L'ARCHE - FRANCE - Tél. + 33 232 989 132 - Fax + 33 232 989 111 - www.briot.com