

LINA *energy efficient and ecologic* 

Esthetic and sustainable lamp.  
Bright and white light, close  
from daylight.



- 17 watts
- 6000° kelvins
- 1440 Lumens
- Guarantee 3 years
- LEDs' lifetime 50 000 hours (this lifetime allow up to 20 years of intensive use without maintenance)
- Color Rendering Index (IRC) 95
- Cable length 3 meters allowing maximum mobility
- Insulation Class II
- Available colors: white, black
- Lamp's base dimensions 69 x 69 mm, H: 115 mm, inter axial: 54,5 mm
- Distance 50 cm: 2500 lux
- Distance 90 cm: 900 lux
- Flexible length: 650 mm or 1000 mm
- Switch on/off or no contact switch
- The 12 LED are housed in an aluminum anodised with a small footprint: diameter 25 mm, length 400 mm.
- LED are protected by a transparent cover made of polycarbonate which allows optimal distribution of light and excellent protection against dust or splash (IP 53).
- LED are located on a printed circuit, effectively cooled by the aluminum profile, which contributes to the effectiveness of the whole.
- Code : LED00400 – LED00400-ISC - LED01400-LED01400-ISC



[lid-lamps.com](http://lid-lamps.com)

Company certified ISO 9001 by